

Levelok® Model PASR-3 Installation Instructions

1. Inspect ladder for damages or excessive wear before affixing shoulder rest. Shoulder rest may not remain attached if ladder rail is not smooth, clean and dry.
2. Be sure to measure and confirm clearances on any ladder racks or carriers before attaching shoulder rest.
3. Determine the best or optimum location on the ladder rail for installation of shoulder rest.
Mark this location with pencil or felt tip marker. This would normally be the balance point of the ladder but may vary depending on the ladder user's preference.
4. Remove and re-affix, to another location, any ladder safety or warning labels that may be in the preferred shoulder rest location.
5. **Attention: Extremely Important** - Clean ladder rail at preferred location with denatured alcohol or other cleaner that is approved for use on fiberglass rails. Let dry before attaching pad.
6. Peel paper off the adhesive-tape on back of shoulder rest.
7. Carefully align shoulder rest over preferred location and firmly press into place. (rivets and / or any rung protrusions should be avoided for a nice, flush fit to the rail)
8. Shoulder Rest can be used immediately.

Another product by Levelok® Corporation

Tel. 360-697-8629 Fax 360-697-5425 toll free 888-811-1727

www.levelok.com Patent # 8,671,542 B2

Copyright by Levelok® 2014