



*P.O. Box 2834  
Poulsbo, WA 98370  
Tel. 360-697-8629  
Fax 360-697-5425*

---

## **Installation of KeyLok Mounting Knobs onto Levelok Permanent Mount Ladder Levelers**

ATTENTION: The existing, 3 threaded studs on each permanent mount ladder leveler will need to be cut so that the new aluminum mounting knobs will fit properly. Please follow the instructions below.

1. Detach (un-mount) permanent mount style levelers from ladder
2. Thread and tighten (snug...not too tight) locknuts back onto the threaded studs.
3. Using the top of the locknut as a guide to determine length, cut threaded stud with sharp hack saw blade. (IMPORTANT: Leave Locknut "On" While Cutting Stud)
4. Slowly back off (remove) the locknut, turning it both directions when nut is close to bolt "end" so that you are certain the threads are clean of metal shavings.
5. Apply a couple of small drops of the metal adhesive included in kit to threaded studs.
6. Thread aluminum mounting knobs onto threaded studs by hand and tighten with a pair of channel lock pliers or similar, paying close attention to not damaging the knobs. Thin rubber or cardboard can be used to protect the knobs when tightening. A good snug fit is all that is needed. Do not overtighten. Allow adhesive to dry overnight.
7. Install KeyLok Base Units per instructions enclosed in kit.
8. Attach and / or detach leveler to base unit.

Extra sets (pairs) of Base Units, model LL-QC-1, are available from Levelok or many of our dealers online. The part number is LL-QC-1. Installation of these base units will enable you to attach your new, quick connect levelers